

T 800 BRUSH SKID SET FITTING INSTRUCTIONS

The T800 Brush Skid set is provided with the accessories shown here. Where the skid assembly is used in a 3" pipe no brushes are required. Provided in the set are brushes suitable for 4" and 6" pipes. Your distributor can provide additional brushes.

The brush holders are retained by means of an expanding clamp controlled by the locking collar that also retains the brushes. To fit or remove the brush holder, it is not necessary to remove the locking collar, just back it off sufficiently to unlock the clamp and allow the camera to be pushed in or out. The locking collar need only be removed to change or replace brushes.

Fitting Brushes

Remove the locking collar from the camera skid and fit eight brushes of suitable length as shown. If using in 75mm pipe, do not fit any brushes.
 Re-fit locking collar, which remains fitted except when changing brushes.

Fitting brush holders

Back off locking collar sufficient to allow camera or adaptor to be pushed into brush holder (approximately 2 turns) but do not remove completely.

Push the camera fully into the skid assembly and tighten rear collar hand tight.

When fitting brush holders to Flexiprobe adaptor, T805 Sonde or to rod termination, appropriate "half shells" must be fitted with the brush holder fitted over them.

When a brush holder is fitted over the Flexiprobe adaptor, the adaptor should be fitted to the rod and the shells and brush holder fitted over it.

We recommend keeping your skid and adaptor assembled when transporting the system. There is no need to disassemble the skid unless a different size pipe is surveyed.

Where an adaptor is not being used the rear skid can be fitted to the Pearpoint ELS termination to provide better centring in the pipe.

When correctly fitted, brushes should look like this with the rear brush fitted over the adaptor, Sonde or Rod Termination.

